



Informational Sheet: Free Air Space

Copper Louver Wall Vent – Arch Top



1 Square Foot of Free Air Space = 250 Square Feet of Attic Space

Free Air for Copper Louver Wall Vent – Arch Top

<u>Roof Vent Size</u>	<u>Free Air Area (Square Inches)</u>	<u>Free Air Area (Square Feet)</u>
8" x 14.5" +/-	48.8 sq. inches +/-	0.34 sq. feet +/-
11 x 14.5" +/-	70.3 sq. inches +/-	0.49 sq. feet +/-
8" x 22.5 +/-	76.9 sq. inches +/-	0.53 sq. feet +/-
11" x 22.5" +/-	115.3 sq. inches +/-	0.80 sq. feet +/-
8" x 30" +/-	105.0 sq. inches +/-	0.73 sq. feet +/-
11" x 30" +/-	157.5 sq. inches +/-	1.09 sq. feet +/-
8" x 35" +/-	123.8 sq. inches +/-	0.86 sq. feet +/-
11" x 35" +/-	185.6 sq. inches +/-	1.29 sq. feet +/-
8" x 40" +/-	142.5 sq. inches +/-	0.99 sq. feet +/-
11" x 40" +/-	213.8 sq. inches +/-	1.48 sq. feet +/-
12" x 14.5" +/-	78.1 sq. inches +/-	0.69 sq. feet +/-
18" x 22.5" +/-	205.0 sq. inches +/-	1.74 sq. feet +/-
24" x 30" +/-	385.0 sq. inches +/-	2.67 sq. feet +/-
Custom Sizes	Please call 877-836-9488	

Copper Summit, Inc.

(p) 877-836-9488

(f) 918-836-3644

donna@coppersummitinc.com

www.coppersummitinc.com