



## Informational Sheet: Free Air Space

### Copper Louver Wall Vent – Rectangular



1 Square Foot of Free Air Space = 250 Square Feet of Attic Space

#### **Free Air for Copper Louver Wall Vent – Rectangular**

<b>Roof Vent Size</b>	<b>Free Air Area (Square Inches)</b>	<b>Free Air Area (Square Feet)</b>
8" x 18" +/-	62.4 sq. inches +/-	0.43 sq. feet +/-
11 x 18" +/-	93.6 sq. inches +/-	0.65 sq. feet +/-
8" x 24" +/-	85.8 sq. inches +/-	0.60 sq. feet +/-
11" x 24" +/-	128.7 sq. inches +/-	0.89 sq. feet +/-
8" x 30" +/-	109.2 sq. inches +/-	0.76 sq. feet +/-
11" x 30" +/-	163.8 sq. inches +/-	1.14 sq. feet +/-
8" x 36" +/-	132.6 sq. inches +/-	0.92 sq. feet +/-
11" x 36" +/-	198.9 sq. inches +/-	1.38 sq. feet +/-
8" x 48" +/-	179.4 sq. inches +/-	1.25 sq. feet +/-
11" x 48" +/-	269.1 sq. inches +/-	1.87 sq. feet +/-
12" x 18" +/-	104.0 sq. inches +/-	0.72 sq. feet +/-
18" x 24" +/-	228.8 sq. inches +/-	1.59 sq. feet +/-
24" x 36" +/-	486.2 sq. inches +/-	3.38 sq. feet +/-
Custom Sizes	Please call 877-836-9488	

Copper Summit, Inc.

(p) 877-836-9488

(f) 918-836-3644

donna@coppersummitinc.com

[www.coppersummitinc.com](http://www.coppersummitinc.com)