



## Informational Sheet: Free Air Space

### Copper Louver Wall Vent – Round



1 Square Foot of Free Air Space = 250 Square Feet of Attic Space

#### Free Air for Copper Louver Wall Vent – Round

<u>Roof Vent Size</u>	<u>Free Air Area (Square Inches)</u>	<u>Free Air Area (Square Feet)</u>
16" +/-	96.2 sq. inches +/-	0.67 sq. feet +/-
20" +/-	159.0 sq. inches +/-	1.10 sq. feet +/-
24" +/-	237.6 sq. inches +/-	1.65 sq. feet +/-
32" +/-	441.8 sq. inches +/-	3.07 sq. feet +/-
34" +/-	502.7 sq. inches +/-	3.49 sq. feet +/-
Custom Sizes	Please call 877-836-9488	

Copper Summit, Inc.

(p) 877-836-9488

(f) 918-836-3644

donna@coppersummitinc.com

[www.coppersummitinc.com](http://www.coppersummitinc.com)